

INFINITY

STACCATO ADJUSTABLE TRIGGER

1

Align the supplied green vinyl template flush with the magazine tunnel.

2

Drill hole location as indicated on template with 5-64" drill bit.

3

Thread the take-up adjustment screw into the top of the trigger guard using the supplied allen key.

Note: Do not overtighten, only install flush to trigger guard

4

Apply blue thread-locker to the top and bottom trigger screws when making your final adjustments.

These parts are designed to be installed and safety checked by professional pistol smiths for use by competitors in sanctioned competition.

No liability will be expressed or implied for damages or injuries which may result from improper installation or use of this product.

Installation of these parts may nullify the warranty of the handgun manufacturer.